

# Wall Hung Installation Guide

## IMPORTANT:

Ensure appropriate structural support behind the finished wall, such as reinforced backing or stud noggins, to securely mount basins and other wall-hung fixtures.

### 1. Marking Height

- Mark the finished top height, accounting for approx. -13mm to allow for bracket height (verify bracket height before installation). See Fig. 1.
- Draw a level line at the top bracket height on the wall.

### 2. Centre Alignment

- Measure and mark the centreline on the wall for top placement.
- Mark the centreline on the mounting bracket.

### 3. Bracket Mounting

- Position the mounting bracket on the wall and mark the MUST-DO fixing points for drilling (refer to image).
- Use the following fixing guide:
  - 250mm, 500mm, 650mm, 800mm brackets: Two fixing points.
  - 1050mm bracket: Three fixing points.
- Ensure the fixing points are as close as possible to the threaded rod on the bracket. See Fig. 2.

### 4. Drilling

- Drill 10mm holes through tiles at the marked points.
- Pre-drill 6.5mm holes for coach bolts. See Fig. 3 for a completed installation.
  - Timber: Use M8 x 75mm coach bolts.
  - Masonry: Use 8mm x 60mm Anka/Dyna bolts.

### 5. Bracket Installation: Secure the bracket to the wall.

### 6. Top Installation

- Guide the moulded top onto the threaded rod.
- Place the large washer first, followed by the smaller washer, and finally the nut.
- Use packers for adjustment, if necessary.
- Do not over tighten bolts.

### 7. Fit taps and waste assemble to basin.

### Optional - Shroud Mount Installation.

1. Mount the shroud bracket onto the wall (refer to image).
2. Ensure the basin is securely fixed and connected.
3. Slide the shroud gently into place and tighten it with the appropriate size bolts at two positions.

